



U-BOAT

ITALO FONTANA

SPECIAL EDITIONS

NEW YORK



Dear Customer

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE USER INSTRUCTIONS.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE **U-CLUB AREA**, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS, SO TO GET ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.

WATCH FUNCTIONS

- A CROWN
- B HOUR HAND
- C MINUTE HAND
- D SECONDS HAND



Representative image.

Some components may be in different positions or not fitted.

AUTOMATIC MECHANICAL • NEW YORK 17

Automatic Mechanical



- **POSITION 1**
NEUTRAL POSITION

- **POSITION 2**
SECOND CLICK

POSITION 1
NEUTRAL POSITION

to wind up and start the watch, turn the crown **A** clockwise.

POSITION 2
SECOND CLICK

pull the crown **A** out to position 2. Turn the crown **A** clockwise to set the desired time.

Press the crown **A** all the way down to return it to position 1.



- Your watch will keep its performance intact for a long time, with proper care.
- We recommend that you have your watch checked every 3-4 years at one of our Authorized Dealers/Authorised Service Centres, to carry out ordinary maintenance on all mechanical parts and water resistance.
- We also recommend contacting an Authorized Dealer/Authorised Service Center to replace the strap.
- Do not leave the watch in places exposed to extreme temperature changes, humidity, the sun and strong magnetic fields.
- Jewel watch, avoid contact with water.

AUTOMATIC WATCHES REQUIRE MANUAL WINDING FOLLOWING A LONG PERIOD OF INACTIVITY.



U-BOAT HEAD OFFICE

Via Pesciatina 751H

Gragnano, Capannori - 55010 Lucca - Italy

Tel: +39 0583 469288 - Fax: +39 0583 462249

www.uboatwatch.com - service@u-boatwatch.com