

**U-BOAT**  
ITALO FONTANA

# DIVE WATCH

SOMMERSO DAMASCUS RIGHT



*Dear Customer*

**WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.**

**IN THIS BOOKLET YOU WILL FIND THE USER INSTRUCTIONS.**

**WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR**

**OFFICIAL WEB SITE IN THE U-CLUB AREA DEDICATED EXCLUSIVELY**

**TO THE U-BOAT WATCHES OWNERS, SO TO GET ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST  
NEWS,**

**EVENTS AND OFFERS.**


# Mechanical Automatic

- A CROWN COVER
- B SCREW CROWN
- C HOUR HAND
- D MINUTE HAND
- E SECONDS HAND
- F 24 HOURS INDICATOR
- G DATE
- H UNIDIRECTIONAL BEZEL



## WATCH FUNCTIONS

Representative image.  
Some components may be in different positions or not fitted.



- **POSITION 1**  
NEUTRAL POSITION
- **POSITION 2**  
FIRST CLICK
- **POSITION 3**  
SECOND CLICK

1. Unscrew the crown cover **A** to access the crown **B**.

**POSITION 1**  
NEUTRAL POSITION

to wind up and start the watch, unscrew the crown **B** and turn it clockwise.

**POSITION 2**  
FIRST CLICK

pull the crown **B** out to position 2. Turn the crown **B** clockwise to set the desired date. **G**

**POSITION 3**  
SECOND CLICK

pull the crown **B** out further to position 3. Rotate the crown **B** to set the desired time. Consider the indicator **F** (24 hours) for the correct click of the date **G**.

2. Press the crown **B** the way down, screwing it carefully to bring it back to position 1. Screw the crown cover **A** carefully until it locks completely.
3. The bezel **H** rotates counterclockwise.



## USER INSTRUCTIONS

Your watch will keep its performance intact for a long time, with proper care.

We recommend that you have your watch checked every 3-4 years at one of our Authorized Dealers/Authorised Service Centres, to carry out ordinary maintenance on all mechanical parts and water resistance.

We also recommend contacting an Authorized Dealer/Authorised Service Center to replace the strap.

Do not leave the watch in places exposed to extreme temperature changes, humidity, the sun and strong magnetic fields.

Always rinse the watch with fresh water after contact with salt water.

**AUTOMATIC WATCHES REQUIRE MANUAL WINDING FOLLOWING A LONG PERIOD OF INACTIVITY.**

# ABSOLUTELY DIVE WATCH

*ASSOLUTAMENTE SOMMERSO*

