

U-BOAT
ITALO FONTANA

DIVE WATCH

CLASSICO 1001



Dear Customer

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE USER INSTRUCTIONS.


WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE **U-CLUB AREA**, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS, SO TO GET ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.

Mechanical Automatic

- A CROWN COVER
- B SCREW CROWN
- C HOUR HAND
- D MINUTE HAND
- E SECONDS HAND
- F DATE
- G MANUAL HELIUM VALVE



Representative image.
Some components may be in different positions or not fitted.



- **POSITION 1**
NEUTRAL POSITION
- **POSITION 2**
FIRST CLICK
- **POSITION 3**
SECOND CLICK

1. Unscrew the crown cover **A** to access the crown **B**.

POSITION 1
NEUTRAL POSITION

to wind up and start the watch, unscrew the crown **B** and turn it clockwise.

POSITION 2
FIRST CLICK

pull the crown **B** out to position 2. Turn the crown **B** clockwise to set the desired date **F**.

POSITION 3
SECOND CLICK

pull the crown **B** out further to position 3. Rotate the crown **B** to set the desired time.

2. Press the crown **B** all the way down, screwing it carefully to bring it back to position 1. Screw the crown cover **A** carefully until it locks completely.



CARE AND MAINTENANCE

- Your watch will keep its performance intact for a long time, with proper care.
- We recommend that you have your watch checked every 3-4 years at one of our Authorized Dealers/Authorised Service Centres, to carry out ordinary maintenance on all mechanical parts and water resistance.
- We also recommend contacting an Authorized Dealer/Authorised Service Center to replace the strap.
- Do not leave the watch in places exposed to extreme temperature changes, humidity, the sun and strong magnetic fields.
- Always rinse the watch with fresh water after contact with salt water.
- To ensure the safety of our valuable diving watch, a helium release valve has been developed to prevent the gas from entering the case during prolonged dives. The helium valve is also a sign of quality: its presence in a diver's watch means that we are dealing with a professional diving watch.

AUTOMATIC WATCHES REQUIRE MANUAL WINDING FOLLOWING A LONG PERIOD OF INACTIVITY.

U-BOAT HEAD OFFICE

Via Pesciatina 751H

Gragnano, Capannori - 55010 Lucca - Italy

Tel: +39 0583 469288 - Fax: +39 0583 462249

www.uboatwatch.com - service@u-boatwatch.com